

REPLACING THE AWNING FABRIC

- If you have a motor, turn it off.
- Manually crank the awning out to full projection
- Remove the front bar end caps
- Using the provided Allen wrench, unloosen the bullets at each end of the front bar C channel.
- Ask your helper to get on a step ladder about five feet from the wall on the non-motor/non-crank side of the awning.
- On a ladder mildly push the front bar toward the wall. This will loosen the fabric
- Remove the fabric by pulling it straight out the C-channel on the non-crank/motor side of the awning. You should pull out the front and back simultaneously.
- Install the new fabric by sliding the ends back into the C-channel from the same side. You may need to push the front bar slightly toward the wall while two helpers feed the beads into the C-channel. There is a slot in the end of the roller eye for it to slide into.
- Reinstall both bullets and tighten the Allen screws.
- Re-install the front end caps
- Retract the awning manually.
- Turn on the motor.

REPLACING THE VALANCE

- Remove the right and left front end caps (I)
- Using the provided Allen wrench, unloosen all the bullets at the ends of the fabric.
- Remove the bullets from the C-channel.
- Remove the valance by pulling on it from the right side.
- Reinstall the new valance by sliding the top bead into the same slots in the front bar (J)
- Reinstall both bullets and tighten the Allen screws.
- Reinstall the right and left front end caps (I)

