

INSTALLING AN ADJUSTABLE PITCH CRANK

STOP!

YOU MUST REMOVE THE AWNING FROM THE MOUNTING BRACKET AND LAY IT SAFELY ON THE GROUND. THIS MUST BE DONE IN THE RETRACTED POSITION. THE ARMS SHOULD BE TIED CLOSED BEFORE REMOVING IT FROM THE BRACKETS.

- After your awning is safely on the ground, remove the nuts and bolts holding the manual pitch brackets to the arms and torsion bar.
- Loosen the front arm bolts slightly (enough for them to move on the bar).
- Remove the manual pitch brackets by sliding them off of the torsion bar.
- Install the adjustable pitch cranks in their place by sliding them onto the torsion bar (you will receive 1 crank per arm when you place an order). The adjustable pitch crank and the front arm brackets will be in a different location from where the brackets were originally.
- Install and tighten all bolts to the arm, torsion bar and front bar.
- Safely re-install and secure the awning to the mounting brackets
- Carefully remove the ties from the arms.
- Your wand is interchangeable, move it from the crank arm to the pitch crank arm as desired.

