

HOW TO ADJUST THE ARMS

It is very easy to adjust the arms. Please do the following:

1. Retract the awning completely
2. **VERY IMPORTANT SAFETY ISSUE:** The arms are high tension and can swing open with out a warning. Tie down the arms with a rope securely
3. Loosen the nuts (do not remove) at the front end of the arms where the arms are attached to the front bar (underneath the valance)
4. Once the nuts are loose enough to slide the plate inside the channel of the front bar then push, pull and lift the arm to be even and straight.
5. Hold the arms in that position by hand and tighten up the nuts at the front end.

This should take care of the problem.